


## DETAILS OF COSBI LINES



Bar number	Distance from		
	From line 1	From previous line	From front of bridge
1	0.00	0.00	-17.48
2	3.00	3.00	-14.48
3	6.04	3.04	-11.44
4	9.12	3.08	-8.36
5	12.24	3.12	-5.24
6	15.40	3.16	-2.08
7	18.60	3.20	1.12
8	21.84	3.24	4.36
9	25.12	3.28	7.64
10	28.45	3.33	10.97
11	31.82	3.37	14.34
12	35.23	3.41	17.75
13	38.69	3.46	21.21
14	42.19	3.50	24.71
15	45.74	3.55	28.26
16	49.33	3.59	31.85
17	52.97	3.64	35.49
18	56.66	3.69	39.18
19	60.40	3.74	42.92
20	64.19	3.79	46.71
21	68.02	3.83	50.54
22	71.90	3.88	54.42
23	75.83	3.93	58.35
24	79.82	3.99	62.34
25	83.86	4.04	66.38
26	87.95	4.09	70.47
27	92.09	4.14	74.61
28	96.29	4.20	78.81
29	100.54	4.25	83.06
30	104.85	4.31	87.37
31	109.21	4.36	91.73
32	113.63	4.42	96.15
33	118.11	4.48	100.63
34	122.65	4.54	105.17
35	127.24	4.59	109.76
36	131.89	4.65	114.41
37	136.60	4.71	119.12
38	141.47	4.87	123.99
39	146.51	5.04	129.03
40	151.72	5.21	134.24

REVISION 1 : SPACING BETWEEN COSBI LINES AMENDED 16 MARCH 2001